



CEMBRIT

CHOOSE THE RIGHT FASTENER AND NAILER FOR THE TASK!

Construction	Type of fastener	ZE 65	PC 65	PC 66	PC 90	PZ-16/50	PQZ-64	PQZ-75 GAS 3G	TA 45	AN450H HP	AN610H HP	AN711H HP	AN911H HP	AN935H HP	
Cembrit Plank mounting on wood															
Cembrit Plank 8 mm	835051 TJEP ZE 25/50 ring nails, HDG	✓													
Cembrit Plank 8 mm	839051 TJEP PC 25/50 ring nails, HDG		✓	✓	✓						✓	✓	✓	✓	
Cembrit Plank 8 mm	839451 TJEP PC 25/51 ring nails, stainless A4		✓	✓	✓						✓	✓	✓	✓	
Cembrit Windstopper Light mounting on wood															
Cembrit Windstopper Light 4.5 mm	836025 TJEP TA 30/25 roofing felt nails, HDG ²⁾								✓	✓					
Cembrit Windstopper Light 4.5 mm	836038 TJEP TA 30/38 roofing felt nails, HDG ²⁾								✓	✓					
Cembrit Windstopper Light 4.5 mm	840238 TJEP PZ-16 staples 38 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Light 4.5 mm	840245 TJEP PZ-16 staples 45 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Light 4.5 mm	840250 TJEP PZ-16 staples 50 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Basic mounting on wood															
Cembrit Windstopper Basic 9 mm	835051 TJEP ZE 25/50 ring nails, HDG	✓													
Cembrit Windstopper Basic 9 mm	839051 TJEP PC 25/50 ring nails, HDG		✓	✓	✓						✓	✓	✓	✓	
Cembrit Windstopper Basic 9 mm	836038 TJEP TA 30/38 roofing felt nails, HDG ²⁾								✓	✓					
Cembrit Windstopper Basic 9 mm	840238 TJEP PZ-16 staples 38 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Basic 9 mm	840245 TJEP PZ-16 staples 45 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Basic 9 mm	840250 TJEP PZ-16 staples 50 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Extreme mounting on wood															
Cembrit Windstopper Extreme 9 mm	835051 TJEP ZE 25/50 ring nails, HDG ³⁾	✓													
Cembrit Windstopper Extreme 9 mm	839051 TJEP PC 25/50 ring nails, HDG ³⁾		✓	✓	✓										
Cembrit Windstopper Extreme 9 mm	836038 TJEP TA 30/38 roofing felt nails, HDG ²⁾³⁾								✓	✓					
Cembrit Windstopper Extreme 9 mm	840238 TJEP PZ-16 staples 38 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Extreme 9 mm	840245 TJEP PZ-16 staples 45 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							
Cembrit Windstopper Extreme 9 mm	840250 TJEP PZ-16 staples 50 mm, with glue, galv. 12μ+ ¹⁾²⁾⁴⁾					✓	✓	✓							

¹⁾ Vertical spacers are installed immediately after installation.
²⁾ Only used if there is no requirement for K1 10 B-s1, d0- (class 1) casing.
³⁾ Used if there is a requirement for the plate to absorb disc effect.
⁴⁾ PL staples can be used at the same length.

CEMBRIT



FASTENER GUIDE

CEMBRIT

